





SCREW-BRACKET ERSATZHALTERUNG/ SPARE SCREW-BRACKET MOUNT



SILIKON-ERSATZHALTERUNG (OPTIONAL)/ SILICONE BRACKET (OPTIONAL)



- 2 x click = on/power
- + 1 x click = standard
- + 1 x click = eco
- + 1 x click = flashing
- + 1 x click = fast-flashing
- + 1 x click = SOS flashing
- + 1 x click 5 sec. = off



Battery control



> 75%

25-75%

< 25%

Ladevorgang Charging Charge



ca. 3 h

Achten Sie bitte darauf, dass die rotmarkierte Abdichtung stets korrekt verschlossen ist. / Please always keep the silicone plug closed after charging.



Micro
USB

(cable & charger not incl.)

Art.-Nr. 18552



LADEGERÄT + MICRO USB KABEL
CHARGER + CHARGING CABLE MICRO-USB

Art.-Nr. 18553



MICRO USB KABEL
CHARGING CABLE MICRO-USB

Art.-Nr. 00460



SCREW-BRACKET ERSATZHALTERUNG
SPARE SCREW-BRACKET MOUNT

Art.-Nr. 00145



SILIKON-ERSATZHALTERUNG
SILICONE BRACKET



USB CHARGING

BUSTER 200

SIGMA-ELEKTRO GmbH

Dr. -Julius-Leber- Straße 15
 D-67433 Neustadt / Weinstraße

SIGMA SPORT USA

3487 Swenson Ave.
 St. Charles, IL 60174, U.S.A.

SIGMA SPORT ASIA

10F, No.192, Zhonggong 2nd Rd.,
 Xitun Dist., Taichung City 407, Taiwan

